

FILE UPDATE GUIDELINES



Giotto

FILE UPDATE GUIDELINES

GIOTTO SET UP FILE UPDATE GUIDELINES

This guideline is designed to help our customers with update of both their graphic and firmware file for the Matisse position indicators. It is a quick guideline that takes on average about 5-10 minutes to complete. Typically MAD creates unique programming for each job. You will have been provided with these files from a MAD team member. Please save the files to a USB stick before proceeding.

TO UPDATE THE GRAPHIC FILE:

- Power on the PI and plug in your USB stick
- Using the menu button on the back of the PI, press enter
- Select updates
- Select the graphic menu
- Select start graphic update
- Select the appropriate update file you wish to use ending with extension ".miss"
- Follow the on screen instructions

TO UPDATE THE FIRMWARE FILE:

- Power on the PI and plug in your USB stick
- Using the menu button behind the PI, press "enter"
- Select "updates"
- Select the "firmware" menu
- Select "start firmware" update
- Select the appropriate update file
- Follow the on screen instructions