


# FILE UPDATE GUIDELINES



# *Matisse*

## FILE UPDATE GUIDELINES

# MATISSE SET UP FILE UPDATE GUIDELINES

This guideline is designed to help our customers with update of both their graphic and firmware file for the Matisse position indicators. It is a quick guideline that takes on average about 5-10 minutes to complete. Typically MAD creates unique programming for each job. You will have been provided with these files from a MAD team member. Please save the files to a USB stick before proceeding.

### TO UPDATE THE GRAPHIC FILE:

- Power on the PI and plug in your USB stick
- Using the menu button on the back of the PI, press enter
- Select updates
- Select the graphic menu
- Select start graphic update
- Select the appropriate update file you wish to use ending with extension ".miss"
- Follow the on screen instructions

### TO UPDATE THE FIRMWARE FILE:

- Power on the PI and plug in your USB stick
- Using the menu button behind the PI, press "enter"
- Select "updates"
- Select the "firmware" menu
- Select "start firmware" update
- Select the appropriate update file
- Follow the on screen instructions